

HANDI-WAY Instant Spray Cleaner

Description: Handi-Way Instant Spray Cleaner is formulated to be especially effective on stubborn soils, greases, fingerprints, pencil marks, smoke film, tobacco stains, waxes, oils, etc. The fast-acting formula is also non-toxic, non-corrosive, and non-flammable.

Directions: Spray evenly over surface, and wipe clean. For heavy soil or grease, allow spray to remain for up to one minute before wiping. Rinse only as needed and on areas where food may contact. DO NOT USE ON WOOD FURNITURE OR PAINTED SURFACES.





Where to Use: wood • plastic • leather • chrome • porcelain • rubber • metal • stainless steel • vinyl • formica • enamel surfaces • aluminum

Recommended For: homes • schools • offices • restaurants • GYM • PARKS • BUSINESSES

Specifications:

COLOR	Light Green	FOAM	Medium
ODOR	Mild Sassafras	RINSABIL	ITYExcellent
COMPOSITIONSvnt	hetic Detergent	VISCOSIT	YMedium



